

# Airlock Maintenance Western District IAOM



July 22, 2021 Presented by Dave Link



## **Rotary Airlock Valves**





## Topics:

- -Inboard/outboard bearings
- -Performance
- -Troubleshooting
- -Maintenance recommendations



## Importance of Airlocks

- Tightly machined internal clearances create air seal
- Used to separate two different pressure/vacuum environments
- Allow for proper performance of pneumatic system
  - Often found on the front end and termination point of conveying system
- Offer consistent and even product feed









## **Inboard Bearing Airlock**

Most common style of airlock


Standard roller bearing with double lip seal installed in the inside of the

endplate

Easy to disassemble and reassemble

Packed bearings for minimal maintenance

BILL OF MATERIAL				
TEM	DESCRIPTION	MODEL	PART NO.	QT
Α	BODY			1
В	ROTOR			1
С	NTI, DOUBLE UP SEALS	6x6 THRU 12x8	NTI1154-3	2
		14x10 THRU 16x12	NII1154-2	
		18×12 THRU 24×16	NT1154.1	
D	LINK BELT BEARINGS	6x6 THRU 12x8	W8 219	2
		14×10 THRU 16×12	WB 223	
		18x 12 THRU 24x 15	WB 231	
E	END PLATE	-		1 2
F	LOCK COLLAR (SUPPLIED W BEARING)	-	-	2
G	SHAFT COVER	-	-	1
н	HHC5, 38"-16 x 1" LG.	616		8
		8x6 THRU 10x8		1:
		12X8 THRU 15X12		10
		18×12 THRU 20×15		2.
		24115		36






#### VJ Series Airlock Valve

- Inboard Bearings
- Most common option for many applications
- NOT considered a NFPA isolation device





## VJ Series Exploded View





#### VJH Series Airlock Valve


- Considered an "Inboard Bearing Airlock"
- Suitable for most common applications
- Apply to higher pressures
- NOT considered a NFPA isolation device





## **Outboard Bearing Airlock**

- Generally used for high heat applications or where material could migrate through an inboard lip seal
- Uses 3 layers of Teflon packing in the endplate
- Timken Bearing is located on the bearing rack which is removed from the endplate
  - is considered an NFPA isolation device.





#### VJX Series Airlock Valve

- Outboard Bearings
- Common for high pressure and abrasion applications
- IS considered a NFPA isolation device






#### Airlock Performance

- Clearances must be properly machined to offer an effective seal
- Typical rotor clearances of .004" (+/-.001")
- Static and dynamic leakage always present
  - Worn clearances will greatly increase leakage
- Typically rated to 15psi or 15"Hg
- Typically operates from 10-30rpm
  - Rotation speed can be critical







#### Airlock Issues

Bearings/Seals

Wear/clearances

Squeaking/squalling

**Bucking** 

**Temperatures** 

Motor trips/overheats



#### Airlock Will Not Turn





Airlock Problem or Motor Issue?



#### **SAFTEY FIRST**



 Do NOT attempt to work on, clean, service valve, open, or remove any protective cover, guard, grate or maintenance panel until the POWER and/or AIR has been turned off and LOCKED OUT

 Never place any part of your body under or near rotating or moving parts of valve







## Troubleshooting

Remove Guard & Detach Chain

Can the Rotor Spin Freely?






## Troubleshooting

Yes: Airlock is Good

> Motor heater settings? Enough HP? Gear Reducer?

No? Time to work on your Airlock!






## Troubleshooting

- Product build-up, wrench, bolts, sticks, etc.
- Rotor shifted
- Product binding
- Check for correct application, T.E.R., chrome body & end plates








- Remove the airlock from system to obtain unobstructed access to rotor.
- Place a block in the airlock to prevent the rotor from turning unexpectedly



**DANGER:** Never place hands or fingers in an airlock, unless it has been disconnected and locked out and a wooden block has been placed in the airlock to prevent the rotor from turning.



- Remove rotor blockage
- a. Using a probe, dislodge the obstruction from the rotor and discard.
  - b. Remove safety block.
  - c. Turn the rotor using the probe to inspect for additional foreign material.
- Check for rotor damage.
- If rotor does not turn freely:
  - a. Locate rotor damage such as burrs or dents on rotor blades.
  - b. Remove any burrs using a file or emery cloth.







Burrs or dents must be removed from the rotor shaft before attempting bearing removal to prevent scoring of inner race.





**CAUTION:** Only insert punch in the unthreaded lock collar hole which is intended for this purpose to prevent irreparable lock collar damage.




FIGURE 9.2



1. Remove the end plate

\*\*If both end plates are removed, they should be marked so that each end plate can be reinstalled on the same end of the airlock body\*\*

- 2. Place the end plate on wooden blocks with the machined surface down.
- 3. Tap the bearing and shaft seal through the end plate using a brass rod and discard both the bearing and the shaft seal.







 Turn the end plate over and install a new bearing using a brass driver

 Pack the bearing void and shaft seal using Keystone Nevastane HT/AW-2 grease







- Seat the seal by slightly tapping with soft hammer
- Reinstall the endplate
- Check rotor clearance before tightening Locking Collars




## **NEW!** Kice Maintenance videos

www.kice.com/products/airlocks/vjx/



#### VJX Cartridge



- Loosen bearing lock collar set screw by turning counter clockwise.
- Disengage bearing lock collar from bearing by turning it using a punch and hammer.



## Noisy Airlock Valve





#### Noisy Airlock Valve

- Is something stuck inside?
- Is your Motor/Airlock turning in correct direction?
- Has there been a major temperature change?



## Don't forget what is around your Airlock









#### Long Term Storage

If the airlock must be stored outdoors, the following precautions should be followed.

- Protect from environment as well as possible by covering to keep out dirt and moisture.
- Store on a skid with a fully covered deck to keep the airlock from resting directly on the ground ensuring the outlet is covered and protected.
- Securely cover inlet using the steps below.
- Remove shipping cover plate.
- Transfer the position of the airlock flange's corner holes to the shipping cover plate and drill through holes.
- Place a gasket on the airlock inlet.
- Bolt shipping cover plate in place.
- Cover motor and drives to prevent ingress of water, dirt and pests.

NOTICE: Turn the rotor a minimum of five revolutions monthly to maintain grease distribution within the bearings



## Types of Kice Airlock Valves







**VJ** Series



**VJH Series** 



**VJX Series** 



**VBS** Series

**VD** Series

**VL Series** 



## In Closing......

- Understand the equipment that you have in operation
  - Understand system behavior in both optimal and upset conditions
- If in doubt or confused, rely on the manufacturer for advice
- Learn to identify and resolve issues before failures
- Regular and effective maintenance pays off
- BE SMART / BE SAFE

Always work smartly and practice safety!!





## Thank you for the opportunity to speak today

